





Cancel or modify a scheduled single recording






You can cancel or modify a Scheduled Recording at any time, even a recording that is currently in progress.

1. Select the **DVR** icon from the Quick Menu.
2. Select **Scheduled Recordings** to view a list of your scheduled recordings.
3. Select a program title and press the **OK Select** button on your remote to view the Program Information screen.
4. Select the **Record**  icon to view your options.
5. Select the **Don't Record this program**  icon to cancel the recording.
6. Select the **Recording Settings**  icon to modify any of the following options:
 - **Save recordings until** — “I Delete” or “Space is Needed.”
 - **Start Recording** — “On Time” or 1-15 minutes early.
 - **End Recording** — “On Time” or up to 2 hours later. This option is great if you are recording a sporting event that may go into overtime.

Cancel or modify a series recording



1. Select the **DVR** icon from the Quick Menu.
2. Select **Series Priority**.
3. Highlight the series you want to cancel or modify and press **OK Select**.
4. Select the **Delete**  icon to cancel the series recording.
5. Select the **Recording Settings**  icon to modify any of the following options:

- **Episode types to Record** — “First Run Only”, “First Run and Repeats”, or “All Episodes”.*
 - **Save no more than** — “1-7”, or “All Episodes”.
 - **Save recordings until** — “Space is Needed” or “I Delete.”
 - **Channels to Record** — “All channels” or “This channel only.”
 - **Start Recording** — “On Time” or 1-15 minutes early.
 - **End Recording** — “On Time” or up to 2 hours later.
6. Select the **Record**  icon to confirm your new selections.

*All Episodes should only be used when recording shows that do not have unique program IDs, like game shows. When selecting All Episodes your DVR will record duplicate shows.