




View a list of programs scheduled to record



To see a list of programs you have scheduled to record in the future:

1. Select the **DVR** icon from the Quick Menu.
2. Select **Scheduled Recordings** to view your list.
 - The **Record**  icon indicates the individual program will record as scheduled.
 - The **Series Record**  icon indicates the series will record as planned.
 - The **Conflict**  icon indicates a scheduling conflict with a specific episode of a series you have scheduled to record.

Note: You can modify your Series Priority List to record a program marked with a **Conflict**  icon. See above for more details.

Tip Scheduled recordings are listed by days of the week. Press **►** on your remote to see scheduled recordings for later in the week.







Play back a recorded program



Play back recordings whenever you want

1. Press the **My DVR** button on your remote or the **DVR** icon from the Quick Menu, then **My Recordings**.
 - You can view and sort your recordings by title, date recorded, and channel. Use the right arrow **►** button to scroll through the different views.
2. Highlight a program you want to play back and press the **OK Select** button on your remote to view the Program Information screen.
3. Select a playback option from the icons at the bottom of the screen.



-  Return to previous screen.
-  Play or resume from previous position.
-  Restart from the beginning.
-  Set a deletion priority for this program.
-  Delete this program.
-  Set locks for title, channel, or rating.

Tip You can play back a previously recorded program while you record two programs at the same time.