

Record a single program



Record from TV Listings

1. Press **Guide** on your remote to view the TV Listings.
2. Highlight the program you want to record.
3. Press the **Record** button on your remote. A red dot appears next to the program title in the grid so you know the program is scheduled to record.



Record while watching TV

1. Simply press **Record** on your remote. A Recording Started notice appears to indicate recording has begun.
2. Press **OK/Select** on your remote to hide the notice, or just wait for it to disappear. Any portion of the program saved in the buffer will also be recorded.

Tip If you want to record a second program at the same time, use the **Step** button to change tuners.



Record from the Program Information screen

1. Press **Guide** on your remote to view the TV Listings.
2. Highlight a program and press **Info** on your remote. The Program Information screen appears.

3. Press **Record** on your remote or select the **Record** icon. A Confirmation screen appears.
4. Press **OK/Select** to record the program as planned, or select the **Recording Settings** icon to modify the recording settings.